




S E A V E R

B E Y O N D P E R F O R M A N C E

GIRTH



SLEEVE


USER GUIDE

GETTING STARTED

Charge your girth sleeve with the included wireless charger.

The girth sleeve has a 10-hour battery life when on and a two week run time on sleep mode.

The girth sleeve automatically switches on when you connect it to the application via Bluetooth.



STANDBY MODE

The girth-sleeve automatically goes to sleep when not connected via Bluetooth, if no training is under way.


USER GUIDE

CHARGING THE GIRTH SLEEVE

Turn the girth sleeve to have the flat side facing you, with the casing on the bottom.

First, plug in the wireless charger into a power outlet. Then, place it on the lower right part of the girth sleeve, behind the casing.

The « horse » logo of the charger should be facing the girth sleeve.




Note: A red light will switch on for just a few seconds on the charger when you plug it in.

USER GUIDE

A red light on the logo side of the charger will turn on to indicate the girth sleeve is charging and turn off when the battery is fully charged.

In order to be able to see this red light and make sure the girth sleeve is charging, you can position it this way while charging:




It will take about 1h/1h30 for the girth sleeve to fully charge. During charging, it might get a little warm, but no worries, this is normal.

USER GUIDE

ATTACHING THE GIRTH SLEEVE TO THE GIRTH

You should have received 4 attachments: 2 long straps for stud girths (1st photo) and 2 velcro straps for thin girths (2nd photo).



You can also use the velcros as an extension of the straps, if you have a big stud girth and the straps are too short.

For thin girths, you can attach the straps around the girth sleeve to make sure it is tightly fixed on the girth.

USER GUIDE

Important:

The girth sleeve needs to be well attached to the girth so as not to move or hang in order to provide you with all the data of your training session.

Otherwise, an error message will display on your application at the end of your training.

Be particularly careful if you have a girth that is thinner than the girth sleeve, as data might be distorted from an improper attachment, with the girth sleeve being too loose on the girth.

USER GUIDE

USING THE ELECTRODES

The second electrode enables the collection of several data such as cardio and calories burned. Before each use of the girth sleeve, for accurate and reliable data, you need to apply water (preferably warm) on the two electrodes as well as directly on your horse with a sponge. You can also put gel on the two electrodes, instead of using water.


PLACING THE WITHERS' ELECTRODE

The second electrode must be placed behind the withers on the left side of the horse, right where the saddle comes in contact with the horse's back.

See the image on the right.

USER GUIDE

PLACING THE WITHERS' ELECTRODE



USER GUIDE

The placement area to have accurate results is quite large, so do not worry if from one training session to another you do not put it at the exact same place.

1. Take the electrode in your hand: the spikes side is to be in direct contact with the horse's skin.
2. After putting the saddle, and right before tightening the girth, put your hand (with the electrode) underneath the saddle pad, as if to raise it off the withers. Put the electrode there, making sure it is maintained by the saddle, with the wire towards the ground.
3. Once the electrode is blocked; tighten the girth and then attach the wire to the snap button on the girth-sleeve: it must go underneath the saddle vertically.

USER GUIDE


Notes:

The electrode was scientifically tested with a pressure sensor pad, and we can assure you – thanks to the material we chose to use in particular – that it does not apply any negative pressure on the horse's back.

We have also considered safety issues: if something were to get caught in the wire, it will automatically come off the snap button to avoid any risk of injuries, without breaking the girth sleeve.

APPLICATION

COMPATIBILITY



- From iOS 8
- From Android 4.4
- Bluetooth 4.0

DOWNLOAD

The Seaver application can be downloaded via standard platforms.




APPLICATION

CONNECTING TO THE APP

Create a Seaver account from the application, and then connect to it. Before being able to launch a training, you will need to connect your girth sleeve to the app.

To do that, click on the Bluetooth button on the home screen of the app. Another page will display, where you will be able to select your girth sleeve and connect it.



APPLICATION

If nothing is displayed on the « connect » page; it means the application does not detect the girth sleeve.

It can happen in three cases:

- if the girth sleeve is not charged
- if the girth sleeve is not nearby
- if you did not activate your location in the parameters of the app

Once you have connected your girth sleeve, it will automatically be updated, if needed. Be aware that this can take some time if you have a poor internet connection.

PRACTICAL INFORMATION

DURING YOUR TRAINING

It is preferable that you keep your phone on you during your session, in order to have data that use your gps (speed, distance...) and for data gathering and retrieval not to take too long at the end of your training.

ABOUT YOUR GIRTH SLEEVE

The Seaver girth sleeve is shock and water resistant.

To improve impermeability, we have added an extra layer of glue to the girth sleeve. It might crack a little, but do not worry it will not affect the electronics.


PRACTICAL INFORMATION

THE MEASURING TAPE


The tape supplied with your Seaver product is 3m (120 inches) long. It will help you take measurements of your horse.

Measuring your horse is an essential part of the horse's profile creation in the Seaver application.

Indeed, our algorithms' thresholds will then be set according to these measurements in order to provide the most accurate results adapted to your horse.




MEASUREMENTS - WITHERS HEIGHT



Bring your horse on a flat and even ground.

If you do not have a height measuring stick, hold the measuring tape vertically behind the horse's fore limbs. Take the measurement from the highest point of the withers to the ground, making sure to keep the tape as straight as possible.


MEASUREMENTS - GIRTH HEIGHT



The girth's height will be required to calculate jumping data such as fence heights.

Hold the measuring tape vertically behind the fore limbs, and place the tip under the belly, right where the girth would be.

MEASUREMENTS - SHOULDER-GIRTH LENGTH



The shoulder-girth length is also necessary to the accuracy of jump height data in particular.

Place your finger on the middle of the girth sleeve's casing, and go up vertically to shoulder level following the belly. Measure the distance between this point and the middle of the horse's shoulder.



S E A V E R

BEYOND PERFORMANCE

www.seaverhorse.com